


CrossOver Lock Quick Start Guide



2. Install the software.

Place the AccessPilot CD into your CD drive. When the opening screen appears, click the "Install Software" button.

Don't install your locks on your doors yet!



3. Set up your users.

Add your users to the software and assign them their iButtons.

4. Set up your locks.

Before mounting your locks on your doors, we suggest you set them up in the AccessPilot software at your desk or worktable, next to your computer. There are a couple of steps in the setup process that require you to go to the lock and return to the PC, so it's easier to have the lock right next to the PC than have to walk to the lock and walk back. (Unless you'd like the exercise!)

5. Customize your locks.

Now that the AccessPilot software knows all about the locks and who'll be using them, you can match up users and locks. For instance, you can give one user's iButton the ability to open the lock at any time on any day, and another the ability to open the lock only Monday through Friday during business hours.

The process, in a nutshell:

1. Tell the software what changes you want made.

2. Save the changes to the Program iButton via the Blue Dot Receptor.

3. Touch the Program iButton to each lock to transfer the changes.

4. Touch the Program iButton to the Blue Dot Receptor to let the software know the changes have been made.

5. Install your locks.

Now that they're all set up, you can install your locks, using the instructions and drilling template the came with them. The locks fit a standard door and adjust to a 2 3/8-inch backset and a 2 3/4-inch backset.

Need another set of installation instructions? You can download it at: http://www.CrossOverLock.com/SupportCenter.htm

CrossOver X25 Lock Installation